

PRO HYDRAULIC2T^{CE}



**NO FUERCE
LA MÁQUINA**

La Garantía
No Cubre su Mal Uso

**DON'T FORCE
THE MACHINE**

The Warranty
Does Not Cover Wrong Use



AJUSTE DE LA VÁLVULA DE LIBERACIÓN DE PRESIÓN: Antes de ejercer la presión con el gato hidráulico CIERRE la válvula de liberación de presión girándola hacia la DERECHA. En este momento el sistema estará listo para ejercer la presión.

IMPORTANTE: Aplique la presión suavemente, una vez llegado al límite de presión no fuerce la máquina, puede provocar pérdidas de aceite y la rotura del sistema hidráulico NO cubiertos por la garantía. Para liberar la presión sobre las placas ABRA la válvula de liberación de presión girándola hacia la IZQUIERDA. El sistema hidráulico liberará la presión y las placas se abrirán automáticamente.

PRESSURE RELEASE VALVE ADJUSTMENT: Before applying pressure with the hydraulic jack CLOSE the pressure release valve turning to the RIGHT. Then the system will be ready to apply pressure.

IMPORTANT: Apply the pressure smoothly once the pressure limit is reached, do not force the machine. May cause oil leaks and hydraulic system failure NOT covered by warranty. To release pressure on the plates, OPEN the pressure release valve by turning it to the LEFT. The hydraulic system will release the pressure and the plates will open automatically.



CERRAR

ABRIR



¡NO FUERCE LA PRENSA!
SI INTENTA APLICAR MÁS PRESIÓN
PUEDA DAÑAR EL PRODUCTO.



DO NOT FORCE THE PRESS!
IF YOU TRY TO APPLY MORE PRESSURE
MAY DAMAGE THE PRODUCT.

